

## PM15B

**IMAGE A**

1- By pressing the plastic clips to allow to rails on carrier mechanism and inside rail the upper viewer (IMAGE A)

**IMAGE B**

2- Fix to down carrier mechanism front in 12 mm on center of module floor with screw (B-1)

3- Fix to inside rail the upper viewer front in 15 mm on center of module bottom with screws (B-2)

4- Set to upper viewer attaching on frame according to cabinet height (B-3) After attach to frame on mounted inside the cabinet upper viewer and bottom carrier (B-4)

5- Fix to connection part of cover on frame using U hook and with nuts (B-5)

6- Fix to cover module on cover connection part with chip board screw (B-6)

7- Close the cover module. After set to square of cover on the lid cover fittings with the set screw (B-7)

8- Fix to baskets on hang plastic on the mechanism (IMAGE B-8)

9- Fit to hang plastic for to change the range of basket (IMAGE B-9)

ITEM PARTS		
NO	PART NAME	PCS.
1	BOTTOM CARRIER	1
2	UPPER VIEWER	1
3	FRAME	1
4	BASKET	4/7
5	COVER CONNECTION PART	2/3
6	U HOOK	2/3
7	HANG PLASTIC	8/14
8	SET SCREW	2
9	NUTS M6	4/6
10	CHIP BOARD SCREW	15-17

STOCK CODE: SMAI IMAGE NO: RSM151

### WOOD BOTTOM BASKET MOUNTING INSTRUCTIONS

S-1515

**IMAGE A**

1-Close and hanger plastic to the profile by 45° (IMAGE A)

**IMAGE B**

2-Adjust the plastic pins on the plastic by pulling down (IMAGE B)

**IMAGE C**

3- Fix the hanger plastic by pulling down (IMAGE C)

**IMAGE D**

4-Push tightly the basket wires and move up on the plastic channels, when you push the basket wires adjust equal distance according to the channels (IMAGE D D-1 D-2)

**IMAGE D-1**

**IMAGE D-2**

**IMAGE E**

5-Center the basket to the hanger seat. (IMAGE E E-1)

**IMAGE E-1**

**IMAGE F**

6- Make sure that both sides hanger plastics are sitted and pressing down gently (IMAGE F)

**NOTE:** Don't use any tools like screwdrivers and hammer, when you fix the baskets.