


# BASE WASTE

## INSTALLATION INSTRUCTIONS

### BW21C2



ITEM PART		
NO	PART DRAWING	PCS
1		1
2		1
3		1
4		1
5		12 Lt. 2
6		10
7		1